

AS400 Mini Slot Relaiskarte mit Kontakt- Interface

Utility Failure	9	Pin Assignment	Function	I/O
UPS On	8	Pin 1	UPS Failure	O/P
Low battery	7	Pin 2	UPS Audible Alarm	O/P
Bypass	6	Pin 3	GND (Common for Pin 4)	Power Ground
Common	5	Pin 4	On/Off	I/P
Remote Shutdown or ON/OFF	4	Pin 5	Common for Relays	Power Supply
GND	3	Pin 6	Bypass Active	O/P
UPS Audible alarm	2	Pin 7	Low Battery	O/P
UPS Failure	1	Pin 8	UPS On	O/P
		Pin 9	Utility Failure	O/P



Function Description

AC Status	AO Status	Reason
Pin 1 & Pin 5 connected	Pin 1 & Pin 5 disconnected	UPS failure
Pin 2 & Pin 5 connected	Pin 2 & Pin 5 disconnected	UPS failure, utility failure, low battery, bypass active
Pin 6 & Pin 5 connected	Pin 6 & Pin 5 disconnected	Bypass active
Pin 7 & Pin 5 connected	Pin 7 & Pin 5 disconnected	Battery voltage is low
Pin 8 & Pin 5 connected	Pin 8 & Pin 5 disconnected	UPS is in inverter mode
Pin 9 & Pin 5 connected	Pin 9 & Pin 5 disconnected	Utility failure